

## **POTHOLE PREP:**

- **Potholes should not be patched unless the temperature is at or above freezing and will remain at or above freezing for at least 5 hours.**
- **Pothole patches should be three inches (3”) or less in thickness (depth):**  
If the pothole is more than 3” deep fill to 2” - 3” below surface with recycled asphalt and compact.
- **Potholes should be dry and clean of all debris.**  
If pothole is contaminated with water or debris, clean and/or heat to dry before application.

## **PotHoleGlue Repair – MIX instructions (dry blend):**

- **Recycled asphalt (RAP) shall be dry, NOT wet** (if wet, only mix an amount that will be placed within 20 minutes and REDUCE the amount of water used during mixing).  
**RAP shall be no greater than ¾” minus containing not less than 20% “fines” (½” minus preferred).**  
**[Good Quality ½” minus crushed granite (dry), may be substituted.]**
- **Mix the dry RAP/aggregate at a ratio of 7:1 with PotHoleGlue (dry blend).**  
Under extreme conditions the use of a little extra PotHoleGlue will speed drying/curing time during colder application temps.
- **Add water at a ratio of 1 ounce per pound of dry blend** (less if RAP/Aggregate was wet).  
The ready mix will be damp only (NOT WET) and may be difficult to mix by hand. Do NOT add more water.

## **APPLICATION:**

- **Place the finished mix into the pothole in such an amount so as to create a slight crown when compaction is completed.**
- **Compact thoroughly**